BAM32414_QRG.qxp 9/8/2006 5:38 PM Page 2

Reference Chart

Select	Category/Play Mode
Disc 1	Search Playlists ■
Disc 2	Search Artists ■
Disc 3	Search Albums ■
Disc 4	Search Genres ■
Disc 5	Shuffle All Albums
Disc 6	Shuffle All Songs

■ To use these play categories, first install and run Acura TTS. You'll find the Acura TTS software application on the Acura Music Link CD-ROM. **See the User's Guide on the Acura Music Link CD-ROM** for more information.

To select a play mode, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) or the CH DISC (▲ and ▼) buttons to scroll thru the disc numbers until the desired disc number is shown on the audio display. Then press and hold either SEEK/SKIP button (⏮/– or ⏭/+) for at least 1 full second (or, on some models, until you hear a beep).

Client Support
For more information about Acura Music Link and Acura TTS, call Acura Client Services at 1-800-382-2238, Monday thru Friday, 6 a.m. to 5 p.m. (PST), or visit *http://musiclink.acura.com.*

©2006 American Honda Motor Co., Inc.
All Rights Reserved.

American Honda accepts no responsibility for any lost data on an iPod, even if the data is lost while using this product.

Apple, the Apple logo, iPod, iPod, iTunes, FireWire, and Mac are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

BAM 30193-32414 (0609) P/N 08865-1H1-501

Installation Note: Acura Music Link can be installed on *applicable* vehicles equipped with factory- and dealer-installed Acura audio systems and Acura CD players/changers. American Honda makes no guarantee that Acura Music Link will operate or operate properly on vehicles equipped with non-Acura audio systems or anon-Acura CD player/changers.

Acura Music Link
Quick Reference Guide

Downloaded from www.Manualslib.com manuals search engine

BAM32414_QRG.qxp 9/8/2006 5:38 PM Page 4

Acura Music Link

Designed specifically for Acura vehicles, Acura Music Link allows you to play music from your Apple® iPod® on your vehicle's audio system. Once connected, you can use the controls on your vehicle's audio system to play music from your iPod, and it charges your iPod battery.

This Quick Reference Guide will help you get started using Acura Music Link quickly. See the User's Guide on the Acura Music Link CD-ROM to learn how to use all of Acura Music Link's features.

Connecting Your iPod



Switch your iPod to music mode. Find the Acura Music Link cable installed inside the glove box, and plug it into the dock connector port located on the bottom of the iPod. When the Acura Music Link cable is properly connected, a check mark appears on the iPod screen (*right*), and the iPod can only be operated using your vehicle's audio system controls.

NOTE: Acura Music Link can be used with any 4th-generation or later iPod (including iPod video, and iPod nano®). It does not work with the iPod shuffle®. Make sure your iPod has been updated with the latest firmware from Apple. Visit *www.apple.com/ipod/download* for more information.

Disconnecting Your iPod

To disconnect the iPod, squeeze both sides of the Acura Music Link cable connector, and unplug the cable. You can connect and disconnect your iPod while the audio system is on or off.

IMPORTANT:

- For your safety, do not connect or disconnect the iPod while driving.
- Secure the iPod in the glove box. Do not place it on or allow it to fall onto the vehicle floor, where it can get stuck under the brake pedal or the accelerator pedal.
- Do not leave the iPod in the vehicle in high temperatures or expose it to extended periods of direct sunlight; doing so may damage it.
- To avoid damaging the Acura Music Link cable, do not pull strongly on the cable. Always keep the connector dry, and cap the connector when it is not in use.

Using the Audio System Controls

Acura Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Acura factory-installed audio systems vary from model to model and have different button names for the same functions.

Playing Music

1. Connect the iPod, turn the ignition switch to the ON (II) or ACC (I) position, and turn on the audio system.
2. Select Acura Music Link by pressing the CD, CD/AUX, CD/AUX/XM, CD/DVD, CD/CHG, DISC, DISC/TAPE, or DISC/AUX button (depending on your Acura model). If the audio system plays a disc in the CD player/changer or the XM radio, press the button again. Acura Music Link begins playback with the last song played on the iPod. If no song is queued, Acura Music Link shuffles all songs in random order.

Selecting a Play Mode

- *To select a play mode*, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) or the CH DISC (▲ and ▼) buttons to scroll thru the disc numbers until **Disc 5** is shown on the audio display. Then press and hold either SEEK/SKIP button (⏮/– or ⏭/+) for at least 1 full second (or, on some models, until you hear a beep).
  - – Press and release the SEEK/SKIP button to skip to the next song (⏭/+) or to the beginning of song currently playing (⏮/–) within an album.
  - – Press and hold either SEEK/SKIP button (⏮/– or ⏭/+) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- *To shuffle all songs in random order,* use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) or the CH DISC (▲ and ▼) buttons to scroll thru the disc numbers until **Disc 6** is shown on the audio display. Then press and hold either SEEK/SKIP button (⏮/– or ⏭/+) for at least 1 full second (or, on some models, until you hear a beep). After selecting Disc 6, press and release the SEEK/SKIP button to skip to the next song (⏭/+) or to the beginning of the song currently playing (⏮/–).

* See the User's Guide on the Acura Music Link CD-ROM for additional play modes/categories.

Downloaded from www.Manualslib.com manuals search engine